



Floor Patch™

Description: All-purpose concrete patching compound that bonds to concrete, brick, masonry, metal, or wood surfaces.

Intended Use: Ideal for patching concrete, brick, masonry, floors, or retaining walls where the concrete has spalled. The material will also bond to wood and metal. Can be used to anchor bolts in concrete.

Product features: **Easy to mix and apply**
Trowelable to 1/4" or more
High compressive strength
Resistant to water, oils, solvents, and alkalis

Limitations: None

Typical Physical Properties: *Technical data should be considered representative or typical only and should not be used for specification purposes.*

Cured 7 days @ 75° F

Color	Light Grey
Mix Ratio	5.5 resin.:1 hard (by wt.): 4.5:1 [by volume]
Mixed Viscosity	Putty - Paste
% Solids by Volume	100
Pot Life @ 75F	45 min.
Application Temperature	60° - 90°F
Temperature Resistance	Dry: 250°F; Wet: 120°F
Minimum Recoat Time @ 75F	6 - 8 hrs.
Cured Hardness	85D
Packaging	30 lb. Unit
Application Coverage per Unit	4.5sq.ft. @ 1/4"/10 lb.unit * 18sq.ft.@1/4"/40 lb.unit
Compressive Strength	8000 psi
Functional Cure	16 hours @ 75°F
Chemical Immersion	7 days @ 75°F

Uncured

Aggregate/Liquid Ratio 6:1 by weight; 4:1 by volume

Surface Preparation: For METAL SURFACES, use a wire brush or sandpaper to remove rust and scale from the surface to be protected. Surfaces may be shot blasted or abraded using a wire wheel for best results. All dirt, grease, and old paint should be removed. All clean dry surface is essential for the best results.

Begin with a sound, clean, dry and roughened, oil-free application surface, as it is essential to the success and performance of this product.

Spot test surface by mixing a small quantity of the resin and hardener without the silica filler. Apply the compound to a small, clean test area. Old paint may wrinkle or lift. If it DOES NOT, wait five (5) days and test the bond strength by scraping surface with a sharp instrument. A pressure-sensitive tape test can also be used as follows: cut an "X" into surface and place tape firmly over the cut. Remove the tape with a hard, fast pull. If the coating fails either test, proceed with instructions for previously coated concrete (see below).

For NEW Poured CONCRETE, allow to fully cure (28 days @ 70°F) prior to application. Remove any curing membrane by sanding or etching with a strong detergent; otherwise, etch surface with Devcon® B-4 environmentally safe acid etch.

For OLD CONCRETE, thoroughly clean surface with a grease-cutting detergent to remove grease and oils, and remove any loose or unsound concrete by chipping, scarifying, shotblasting, sanding, or grinding. Proceed as for new poured concrete.

For PREVIOUSLY COATED CONCRETE, applications should be considered short term because the coating system is only as strong as its weakest component. Remove any peeling or degraded paint by sanding or using a paint stripper. For intact paint, thoroughly clean the surface with a strong detergent, then lightly sand to remove any gloss. Treat any areas worn down to the original concrete as bare concrete.

Apply Devcon Concrete Primer 1000 to all shot-blasted or etched concrete surfaces to seal them prior to the application of other Devcon® Floor Savers™ products.

Mixing Instructions:

---- Adequate ventilation is necessary when mixing this product.----

1. Attach a propeller-type Jiffy Mixer Model ES to an electric drill.
2. Mix resin until gray color is uniform throughout the pail.
3. Pour hardener into resin pail.
4. Mix for about two (2) minutes, while continuously scraping material away from sides and bottom of container.
5. Slowly and evenly, pour aggregate* into liquid mixture and mix** until a uniform texture is obtained.

*Using less aggregate than provided will produce a pourable mixture.

**Materials can be mixed by hand on a mortarboard or a clean, flat mixing surface once aggregate has been added.

Application Instructions:

Spread Floor Patch™ over application area with a trowel. Spread back and forth to create the top layer. To produce a smooth finish, trowel again once product has thickened (approx. 20 minutes into pot life).

FOR A TRULY SMOOTH FINISH:

Dip trowel in water before each application to lessen build-up on trowel and break surface tension of epoxy. DO NOT pour water onto uncured epoxy.

Storage:

Store at room temperature.

Compliances:

Approved in the U.S. for use in meat and poultry processing plants. Accepted by Canadian Department of Agriculture Food Safety Service

Chemical Resistance:

Chemical resistance is calculated with a 7 day, room temp. cure (30 days immersion) @ 75°F

Ammonia	Very good	Toluene	Poor
Chlorinated Solvent	Very good		
Hydrochloric 10%	Very good		
Kerosene	Very good		
Methanol	Fair		
Perchloroethylene	Fair		
Sodium Hydroxide 10%	Very good		
Sulfuric 10%	Very good		

Precautions:

Please refer to the appropriate material safety data sheet (MSDS) prior to using this product.

For technical assistance, please call 1-800-933-8266

FOR INDUSTRIAL USE ONLY

Warranty:

Devcon will replace any material found to be defective. Because the storage, handling and application of this material is beyond our control, we can accept no liability for the results obtained.

Disclaimer:

All information on this data sheet is based on laboratory testing and is not intended for design purposes. ITW Devcon makes no representations or warranties of any kind concerning this data.

Order Information:

13100 10 lb.
13120 40 lb.